



**Note: Unless you are sure of your part number, please email us your model & spec number so we can ensure you get the right part and that there are no further modifications required.**

Parts look up sometimes depends on a variety of issues (such as date code or other markings) The list below is derived from a "where used" search of either the part in question or a superseded (prior) part and can not take into account potential part variations that depend on other factors (such as date code) Unless you are 100% sure this is your part you should verify by looking the part up at either **www.smallenginepartssuppliers.com**

[www.smallenginepartssuppliers.com](http://www.smallenginepartssuppliers.com)

No claim of wrong part received will be honored based on the information presented in this file. You must have a WRITTEN (via email) recommendation to claim wrong part received.

The alternator or regulator below can be found at the following page:

[http://www.smallenginesuppliers.com/shop/html/pages/Briggs\\_Stratton\\_ignition\\_coil.html](http://www.smallenginesuppliers.com/shop/html/pages/Briggs_Stratton_ignition_coil.html)

Where Used: 696579

Model Name Diagram

- 294447-1155-A1 Alternators, Control Panels, Wires, Ignition
- 294447-1155-E1 Alternators, Control Panels, Wires, Ignition
- 294447-1261-E1 Alternators, Control Panels, Wires, Ignition
- 295447-0141-E1 Alternator, Ignition
- 303447-1057-E1 Alternator, Ignition, Wires
- 303447-1110-E1 Alternator, Ignition, Wires
- 303447-1236-A1 Alternator, Ignition, Wires
- 303447-1236-E1 Alternator, Ignition, Wires
- 303447-1278-E1 Alternator, Ignition, Wires
- 303447-1278-E2 Alternator, Ignition, Wires
- 303447-1295-E1 Alternator, Ignition, Wires
- 303447-1306-E1 Alternator, Ignition, Wires
- 303447-1306-E9 Alternator, Ignition, Wires
- 303447-1311-E1 Alternator, Ignition, Wires
- 303447-1322-E1 Alternator, Ignition, Wires
- 303447-1322-E9 Alternator, Ignition, Wires
- 303447-1331-E1 Alternator, Ignition, Wires
- 303447-1348-E1 Alternator, Ignition, Wires
- 303447-1384-E1 Alternator, Ignition, Wires
- 303447-1384-E2 Alternator, Ignition, Wires
- 303447-1416-E1 Alternator, Ignition, Wires
- 305446-0194-E1 Alternator, Regulator, Wire Assemblies, Inverter, Electronic Module
- 305446-0194-E9 Alternator, Regulator, Wire Assemblies, Inverter, Electronic Module
- 305447-0119-E1 Alternator, Regulator, Wire Assemblies, Inverter, Electronic Module
- 305447-0135-E1 Alternator, Regulator, Wire Assemblies, Inverter, Electronic Module

305447-0139-E1 Alternator, Regulator, Wire Assemblies, Inverter, Electronic Module  
305447-0139-E2 Alternator, Regulator, Wire Assemblies, Inverter, Electronic Module

Page 1 of 24

305447-0147-E1 Alternator, Regulator, Wire Assemblies, Inverter, Electronic Module  
305447-0177-E1 Alternator, Regulator, Wire Assemblies, Inverter, Electronic Module  
305447-0177-E9 Alternator, Regulator, Wire Assemblies, Inverter, Electronic Module  
305447-0181-E1 Alternator, Regulator, Wire Assemblies, Inverter, Electronic Module  
305447-0184-E1 Alternator, Regulator, Wire Assemblies, Inverter, Electronic Module  
305447-0186-E1 Alternator, Regulator, Wire Assemblies, Inverter, Electronic Module  
350447-1009-A1 Alternator, Ignition  
350447-1009-E1 Alternator, Ignition  
350447-1009-E2 Alternator, Ignition  
350447-1009-E9 Alternator, Ignition  
350447-1012-A1 Alternator, Ignition  
350447-1012-E1 Alternator, Ignition  
350447-1028-A1 Alternator, Ignition  
350447-1029-A1 Alternator, Ignition  
350447-1029-E1 Alternator, Ignition  
350447-1057-E1 Alternator, Ignition  
350447-1108-E1 Alternator, Ignition  
350447-1241-E1 Alternator, Ignition  
350447-1241-E3 Alternator, Ignition  
350447-1264-E1 Alternator, Ignition  
350447-1276-E1 Alternator, Ignition  
350447-1282-E1 Alternator, Ignition  
350447-1288-E1 Alternator, Ignition  
350447-1288-E9 Alternator, Ignition  
350447-1299-E1 Alternator, Ignition  
351447-1045-E1 Alternator, Ignition  
351777-1143-E1 Alternator, Controls, Ignition, Governor Spring  
356442-0065-B1 Alternator, Ignition  
356442-0065-E1 Alternator, Ignition

Page 2 of 24

356442-0065-E9 Alternator, Ignition  
356442-0119-E1 Alternator, Ignition  
356442-0119-G1 Alternator, Ignition  
356442-0126-E1 Alternator, Ignition  
356442-0126-G1 Alternator, Ignition  
356442-0127-B1 Alternator, Ignition  
356442-0127-E1 Alternator, Ignition  
356442-0127-E9 Alternator, Ignition  
356442-0128-B1 Alternator, Ignition  
356442-0128-E1 Alternator, Ignition  
356442-0128-E9 Alternator, Ignition  
356442-0186-B1 Alternator, Ignition  
356442-0186-E1 Alternator, Ignition  
356442-0186-E9 Alternator, Ignition  
356445-0173-E1 Alternator, Ignition  
356447-0075-E1 Alternator, Ignition  
356447-0075-G1 Alternator, Ignition  
356447-0078-E1 Alternator, Ignition  
356447-0078-G1 Alternator, Ignition

356447-0079-E1 Alternator, Ignition  
356447-0079-G1 Alternator, Ignition  
356447-0096-B1 Alternator, Ignition  
356447-0096-E1 Alternator, Ignition  
356447-0096-E9 Alternator, Ignition  
356447-0114-E1 Alternator, Ignition  
356447-0114-G1 Alternator, Ignition  
356447-0115-E1 Alternator, Ignition  
356447-0115-G1 Alternator, Ignition  
356447-0117-E1 Alternator, Ignition

Page 3 of 24

356447-0117-G1 Alternator, Ignition  
356447-0118-E1 Alternator, Ignition  
356447-0118-G1 Alternator, Ignition  
356447-0121-E1 Alternator, Ignition  
356447-0121-G1 Alternator, Ignition  
356447-0122-B1 Alternator, Ignition  
356447-0122-E1 Alternator, Ignition  
356447-0122-E9 Alternator, Ignition  
356447-0123-E1 Alternator, Ignition  
356447-0123-G1 Alternator, Ignition  
356447-0124-E1 Alternator, Ignition  
356447-0124-G1 Alternator, Ignition  
356447-0125-B1 Alternator, Ignition  
356447-0125-E1 Alternator, Ignition  
356447-0125-E9 Alternator, Ignition  
356447-0129-E2 Alternator, Ignition  
356447-0129-G2 Alternator, Ignition  
356447-0133-E1 Alternator, Ignition  
356447-0133-G1 Alternator, Ignition  
356447-0135-E1 Alternator, Ignition  
356447-0135-G1 Alternator, Ignition  
356447-0139-E1 Alternator, Ignition  
356447-0139-G1 Alternator, Ignition  
356447-0140-E1 Alternator, Ignition  
356447-0140-E2 Alternator, Ignition  
356447-0140-G1 Alternator, Ignition  
356447-0140-G2 Alternator, Ignition  
356447-0141-E1 Alternator, Ignition  
356447-0141-G1 Alternator, Ignition

Page 4 of 24

356447-0142-E1 Alternator, Ignition  
356447-0142-G1 Alternator, Ignition  
356447-0145-E1 Alternator, Ignition  
356447-0145-G1 Alternator, Ignition  
356447-0148-B1 Alternator, Ignition  
356447-0148-E1 Alternator, Ignition  
356447-0148-E9 Alternator, Ignition  
356447-0149-E1 Alternator, Ignition  
356447-0149-G1 Alternator, Ignition  
356447-0150-E1 Alternator, Ignition  
356447-0150-G1 Alternator, Ignition

356447-0152-E1 Alternator, Ignition  
356447-0154-E1 Alternator, Ignition  
356447-0154-G1 Alternator, Ignition  
356447-0155-E1 Alternator, Ignition  
356447-0155-G1 Alternator, Ignition  
356447-0156-E1 Alternator, Ignition  
356447-0157-E1 Alternator, Ignition  
356447-0157-G1 Alternator, Ignition  
356447-0158-E1 Alternator, Ignition  
356447-0158-G1 Alternator, Ignition  
356447-0159-E1 Alternator, Ignition  
356447-0159-G1 Alternator, Ignition  
356447-0160-B1 Alternator, Ignition  
356447-0160-E1 Alternator, Ignition  
356447-0160-E9 Alternator, Ignition  
356447-0161-E1 Alternator, Ignition  
356447-0161-G1 Alternator, Ignition  
356447-0162-E1 Alternator, Ignition

Page 5 of 24

356447-0162-G1 Alternator, Ignition  
356447-0163-E1 Alternator, Ignition  
356447-0163-G1 Alternator, Ignition  
356447-0164-E1 Alternator, Ignition  
356447-0164-G1 Alternator, Ignition  
356447-0168-B1 Alternator, Ignition  
356447-0168-E1 Alternator, Ignition  
356447-0168-E9 Alternator, Ignition  
356447-0169-E1 Alternator, Ignition  
356447-0169-G1 Alternator, Ignition  
356447-0171-E1 Alternator, Ignition  
356447-0171-G1 Alternator, Ignition  
356447-0172-E1 Alternator, Ignition  
356447-0172-G1 Alternator, Ignition  
356447-0174-E1 Alternator, Ignition  
356447-0174-G1 Alternator, Ignition  
356447-0177-E1 Alternator, Ignition  
356447-0177-G1 Alternator, Ignition  
356447-0179-E1 Alternator, Ignition  
356447-0179-G1 Alternator, Ignition  
356447-0180-B1 Alternator, Ignition  
356447-0180-E1 Alternator, Ignition  
356447-0180-E9 Alternator, Ignition  
356447-0183-B1 Alternator, Ignition  
356447-0183-E1 Alternator, Ignition  
356447-0183-E9 Alternator, Ignition  
356447-0189-E1 Alternator, Ignition  
356447-0189-G1 Alternator, Ignition  
356447-0191-B1 Alternator, Ignition

Page 6 of 24

356447-0191-E1 Alternator, Ignition  
356447-0191-E9 Alternator, Ignition  
356447-0194-E1 Alternator, Ignition

356447-0194-G1 Alternator, Ignition  
356447-0197-E1 Alternator, Ignition  
356447-0197-G1 Alternator, Ignition  
356447-0199-E1 Alternator, Ignition  
356447-0199-G1 Alternator, Ignition  
356447-0200-E1 Alternator, Ignition  
356447-0200-G1 Alternator, Ignition  
356447-0201-E1 Alternator, Ignition  
356447-0201-G1 Alternator, Ignition  
356447-0202-E1 Alternator, Ignition  
356447-0202-G1 Alternator, Ignition  
356447-0203-E1 Alternator, Ignition  
356447-0203-G1 Alternator, Ignition  
356447-0206-B1 Alternator, Ignition  
356447-0206-E1 Alternator, Ignition  
356447-0206-E9 Alternator, Ignition  
356447-0215-E1 Alternator, Ignition  
356447-0215-G1 Alternator, Ignition  
356447-0216-E1 Alternator, Ignition  
356447-0216-G1 Alternator, Ignition  
356447-0217-E1 Alternator, Ignition  
356447-0217-G1 Alternator, Ignition  
356447-0218-E1 Alternator, Ignition  
356447-0218-E9 Alternator, Ignition  
356447-0219-E1 Alternator, Ignition  
356447-0219-G1 Alternator, Ignition

Page 7 of 24

356447-0220-E1 Alternator, Ignition  
356447-0220-G1 Alternator, Ignition  
356447-0331-E1 Alternator, Ignition  
356447-0331-G1 Alternator, Ignition  
35644A-0116-E1 Alternator, Ignition  
35644A-0116-G1 Alternator, Ignition  
35644A-0166-E1 Alternator, Ignition  
35644A-0166-G1 Alternator, Ignition  
35644A-0167-B1 Alternator, Ignition  
35644A-0167-E1 Alternator, Ignition  
35644A-0167-E9 Alternator, Ignition  
35644A-0175-E1 Alternator, Ignition  
35644A-0175-G1 Alternator, Ignition  
356777-0110-E1 Alternator, Ignition, Controls, Springs  
381442-0102-E1 Alternator, Ignition  
381442-0194-E1 Alternator, Ignition  
381442-0256-E1 Alternator, Ignition  
381446-0252-E1 Alternator, Ignition  
381447-0023-E1 Alternator, Ignition  
381447-0024-E1 Alternator, Ignition  
381447-0048-E2 Alternator, Ignition  
381447-0064-E1 Alternator, Ignition  
381447-0074-E1 Alternator, Ignition  
381447-0075-E1 Alternator, Ignition  
381447-0075-E2 Alternator, Ignition

381447-0077-E1 Alternator, Ignition  
381447-0079-E1 Alternator, Ignition  
381447-0096-E1 Alternator, Ignition  
381447-0111-E1 Alternator, Ignition

Page 8 of 24

381447-0114-E1 Alternator, Ignition  
381447-0116-E1 Alternator, Ignition  
381447-0117-E1 Alternator, Ignition  
381447-0118-E1 Alternator, Ignition  
381447-0119-E1 Alternator, Ignition  
381447-0130-E1 Alternator, Ignition  
381447-0134-E1 Alternator, Ignition  
381447-0135-E1 Alternator, Ignition  
381447-0136-E1 Alternator, Ignition  
381447-0137-E1 Alternator, Ignition  
381447-0140-E1 Alternator, Ignition  
381447-0143-E1 Alternator, Ignition  
381447-0144-E1 Alternator, Ignition  
381447-0144-E2 Alternator, Ignition  
381447-0145-E1 Alternator, Ignition  
381447-0146-E1 Alternator, Ignition  
381447-0149-E1 Alternator, Ignition  
381447-0150-E1 Alternator, Ignition  
381447-0151-E1 Alternator, Ignition  
381447-0152-E1 Alternator, Ignition  
381447-0156-E1 Alternator, Ignition  
381447-0158-E1 Alternator, Ignition  
381447-0171-E1 Alternator, Ignition  
381447-0178-E1 Alternator, Ignition  
381447-0181-E1 Alternator, Ignition  
381447-0181-E2 Alternator, Ignition  
381447-0193-E1 Alternator, Ignition  
381447-0196-E1 Alternator, Ignition  
381447-0221-E1 Alternator, Ignition

Page 9 of 24

381447-0228-E1 Alternator, Ignition  
381447-0233-E1 Alternator, Ignition  
381447-0235-E1 Alternator, Ignition  
381447-0245-E1 Alternator, Ignition  
381447-0245-E2 Alternator, Ignition  
381447-0246-E1 Alternator, Ignition  
381447-0247-E1 Alternator, Ignition  
381447-0248-E1 Alternator, Ignition  
381447-0249-E1 Alternator, Ignition  
381447-0250-E1 Alternator, Ignition  
381447-0251-E1 Alternator, Ignition  
381447-0253-E1 Alternator, Ignition  
381447-0254-E1 Alternator, Ignition  
381447-0255-E1 Alternator, Ignition  
381447-0257-E1 Alternator, Ignition  
381447-0258-E1 Alternator, Ignition  
381447-0258-E2 Alternator, Ignition

381447-0261-E1 Alternator, Ignition  
381447-0266-E1 Alternator, Ignition  
381447-0268-E1 Alternator, Ignition  
381447-0268-E2 Alternator, Ignition  
381447-0270-E1 Alternator, Ignition  
381447-0271-E1 Alternator, Ignition  
381447-0273-E1 Alternator, Ignition  
381447-0274-E1 Alternator, Ignition  
381447-0275-E1 Alternator, Ignition  
381447-0277-E1 Alternator, Ignition  
381447-0279-E1 Alternator, Ignition  
381447-0280-E1 Alternator, Ignition

Page 10 of 24

381447-0306-E1 Alternator, Ignition  
385447-0119-E1 Alternator, Ignition  
385447-0119-G1 Alternator, Ignition  
385447-0126-E1 Alternator, Ignition  
385447-0126-G1 Alternator, Ignition  
385447-0253-E1 Alternator, Ignition  
385447-0253-G1 Alternator, Ignition  
386442-0115-E1 Alternators, Wires, Ignition, Regulators  
386442-0115-G1 Alternators, Wires, Ignition, Regulators  
386446-0193-G1 Alternators, Wires, Ignition, Regulators  
386447-0020-G1 Alternators, Wires, Ignition, Regulators  
386447-0021-E1 Alternators, Wires, Ignition, Regulators  
386447-0021-G1 Alternators, Wires, Ignition, Regulators  
386447-0047-G1 Alternators, Wires, Ignition, Regulators  
386447-0048-G1 Alternators, Wires, Ignition, Regulators  
386447-0065-E1 Alternators, Wires, Ignition, Regulators  
386447-0065-E2 Alternators, Wires, Ignition, Regulators  
386447-0065-G1 Alternators, Wires, Ignition, Regulators  
386447-0065-G2 Alternators, Wires, Ignition, Regulators  
386447-0077-E1 Alternators, Wires, Ignition, Regulators  
386447-0077-G1 Alternators, Wires, Ignition, Regulators  
386447-0079-E1 Alternators, Wires, Ignition, Regulators  
386447-0079-G1 Alternators, Wires, Ignition, Regulators  
386447-0100-E1 Alternators, Wires, Ignition, Regulators  
386447-0112-E1 Alternators, Wires, Ignition, Regulators  
386447-0112-G1 Alternators, Wires, Ignition, Regulators  
386447-0113-E1 Alternators, Wires, Ignition, Regulators  
386447-0114-E1 Alternators, Wires, Ignition, Regulators  
386447-0114-G1 Alternators, Wires, Ignition, Regulators

Page 11 of 24

386447-0116-E1 Alternators, Wires, Ignition, Regulators  
386447-0116-G1 Alternators, Wires, Ignition, Regulators  
386447-0119-E1 Alternators, Wires, Ignition, Regulators  
386447-0119-G1 Alternators, Wires, Ignition, Regulators  
386447-0120-E1 Alternators, Wires, Ignition, Regulators  
386447-0121-E1 Alternators, Wires, Ignition, Regulators  
386447-0121-G1 Alternators, Wires, Ignition, Regulators  
386447-0122-E1 Alternators, Wires, Ignition, Regulators  
386447-0122-E2 Alternators, Wires, Ignition, Regulators





386447-0171-E1 Alternators, Wires, Ignition, Regulators  
386447-0171-G1 Alternators, Wires, Ignition, Regulators  
386447-0172-E1 Alternators, Wires, Ignition, Regulators  
386447-0172-G1 Alternators, Wires, Ignition, Regulators  
386447-0173-E1 Alternators, Wires, Ignition, Regulators  
386447-0173-G1 Alternators, Wires, Ignition, Regulators  
386447-0175-E1 Alternators, Wires, Ignition, Regulators  
386447-0176-E1 Alternators, Wires, Ignition, Regulators  
386447-0176-G1 Alternators, Wires, Ignition, Regulators  
386447-0177-E1 Alternators, Wires, Ignition, Regulators  
386447-0177-G1 Alternators, Wires, Ignition, Regulators  
386447-0179-G1 Alternators, Wires, Ignition, Regulators  
386447-0180-E1 Alternators, Wires, Ignition, Regulators  
386447-0181-E1 Alternators, Wires, Ignition, Regulators  
386447-0181-G1 Alternators, Wires, Ignition, Regulators  
386447-0182-E1 Alternators, Wires, Ignition, Regulators  
386447-0182-G1 Alternators, Wires, Ignition, Regulators  
386447-0183-E1 Alternators, Wires, Ignition, Regulators  
386447-0183-G1 Alternators, Wires, Ignition, Regulators  
386447-0185-E1 Alternators, Wires, Ignition, Regulators  
386447-0185-G1 Alternators, Wires, Ignition, Regulators  
386447-0187-G1 Alternators, Wires, Ignition, Regulators  
386447-0189-G1 Alternators, Wires, Ignition, Regulators  
386447-0190-G1 Alternators, Wires, Ignition, Regulators  
386447-0191-G1 Alternators, Wires, Ignition, Regulators  
386447-0194-G1 Alternators, Wires, Ignition, Regulators  
386447-0195-G1 Alternators, Wires, Ignition, Regulators  
386447-0196-G1 Alternators, Wires, Ignition, Regulators

Page 14 of 24

386447-0198-G1 Alternators, Wires, Ignition, Regulators  
386447-0199-G1 Alternators, Wires, Ignition, Regulators  
386447-0201-G1 Alternators, Wires, Ignition, Regulators  
472177-0100-E1 Alternator, Ignition, Electric Starter, Controls  
473177-0100-E1 Alternator, Ignition, Springs, Electric Starter, Controls  
473177-0111-E1 Alternator, Ignition, Springs, Electric Starter, Controls  
473177-0112-E1 Alternator, Ignition, Springs, Electric Starter, Controls  
473177-0114-E1 Alternator, Ignition, Springs, Electric Starter, Controls  
474177-0100-E1 Alternator, Controls, Ignition, Springs  
474177-0112-E1 Alternator, Controls, Ignition, Springs  
540477-0110-E1 Electric Starter, Alternator, Ignition, Wires  
540477-0112-E1 Electric Starter, Alternator, Ignition, Wires  
540477-0112-G1 Electric Starter, Alternator, Ignition, Wires  
540477-0113-G1 Electric Starter, Alternator, Ignition, Wires  
540477-0116-G1 Electric Starter, Alternator, Ignition, Wires  
540477-0117-G1 Electric Starter, Alternator, Ignition, Wires  
540477-1116-G1 Electric Starter, Alternator, Ignition, Wires  
541477-0100-E1 Alternator, Electric Starter, Harness, Ignitions  
541477-0111-E1 Alternator, Electric Starter, Harness, Ignitions  
541477-0112-E1 Alternator, Electric Starter, Harness, Ignitions  
541477-0113-E1 Alternator, Electric Starter, Harness, Ignitions  
541477-0114-E1 Alternator, Electric Starter, Harness, Ignitions  
541477-0115-E1 Alternator, Electric Starter, Harness, Ignitions

541477-0117-E1 Alternator, Electric Starter, Harness, Ignitions  
541477-0118-E1 Alternator, Electric Starter, Harness, Ignitions  
541477-0120-E1 Alternator, Electric Starter, Harness, Ignitions  
541477-0121-E1 Alternator, Electric Starter, Harness, Ignitions  
541477-0124-E1 Alternator, Electric Starter, Harness, Ignitions  
541477-0125-E1 Alternator, Electric Starter, Harness, Ignitions

Page 15 of 24

541477-0126-E1 Alternator, Electric Starter, Harness, Ignitions  
541477-1112-E1 Alternator, Electric Starter, Harness, Ignitions  
541477-1113-E1 Alternator, Electric Starter, Harness, Ignitions  
541477-1115-E1 Alternator, Electric Starter, Harness, Ignitions  
541477-1120-E1 Alternator, Electric Starter, Harness, Ignitions  
541477-1127-E1 Alternator, Electric Starter, Harness, Ignitions  
541477-1129-E1 Alternator, Electric Starter, Harness, Ignitions

541777-0110-E1 Air Guides, Alternator, Starter Motor, Wires

541777-1110-E1 Air Guides, Alternator, Starter Motor, Wires

542477-0100-E1 WIRES, ALTERNATOR, IGNITION

542477-0110-E1 WIRES, ALTERNATOR, IGNITION

542477-0111-E1 WIRES, ALTERNATOR, IGNITION

542477-0112-E1 WIRES, ALTERNATOR, IGNITION

542477-0113-E1 WIRES, ALTERNATOR, IGNITION

542477-0114-E1 WIRES, ALTERNATOR, IGNITION

542477-0115-E1 WIRES, ALTERNATOR, IGNITION

542477-0116-E1 WIRES, ALTERNATOR, IGNITION

542477-0118-E1 WIRES, ALTERNATOR, IGNITION

542477-0120-E1 WIRES, ALTERNATOR, IGNITION

542477-0121-E1 WIRES, ALTERNATOR, IGNITION

542477-0122-E1 WIRES, ALTERNATOR, IGNITION

542477-0123-E1 WIRES, ALTERNATOR, IGNITION

542477-0124-E1 WIRES, ALTERNATOR, IGNITION

542477-0125-E1 WIRES, ALTERNATOR, IGNITION

542477-0127-E1 WIRES, ALTERNATOR, IGNITION

542477-0128-E1 WIRES, ALTERNATOR, IGNITION

542477-1120-E1 WIRES, ALTERNATOR, IGNITION

542477-1121-E1 WIRES, ALTERNATOR, IGNITION

542477-1125-E1 WIRES, ALTERNATOR, IGNITION

Page 16 of 24

542477-1127-E1 WIRES, ALTERNATOR, IGNITION

542777-0113-E1 Air Guides, Alternator, Electric Starter, Ignition

542777-1113-E1 Air Guides, Alternator, Electric Starter, Ignition

543277-0078-E1 Muffler, Electric Starter, Alternator, Wires/Ignition

543277-0100-E1 Muffler, Electric Starter, Alternator, Wires/Ignition

543277-0112-01 Muffler, Electric Starter, Alternator, Wires/Ignition

543277-0112-E1 Muffler, Electric Starter, Alternator, Wires/Ignition

543277-0115-E1 Muffler, Electric Starter, Alternator, Wires/Ignition

543277-0117-E1 Muffler, Electric Starter, Alternator, Wires/Ignition

543477-0048-E1 Alternators, Wiring Harnesses, Ignitions, Electric Starter, Key Switch

543477-0065-E1 Alternators, Wiring Harnesses, Ignitions, Electric Starter, Key Switch

543477-0076-E1 Alternators, Wiring Harnesses, Ignitions, Electric Starter, Key Switch

543477-0078-E1 Alternators, Wiring Harnesses, Ignitions, Electric Starter, Key Switch

543477-0079-E1 Alternators, Wiring Harnesses, Ignitions, Electric Starter, Key Switch

543477-0100-E1 Alternators, Wiring Harnesses, Ignitions, Electric Starter, Key Switch



543477-1111-E1 Alternators, Wiring Harnesses, Ignitions, Electric Starter, Key Switch  
543477-1118-E1 Alternators, Wiring Harnesses, Ignitions, Electric Starter, Key Switch  
543477-1121-E1 Alternators, Wiring Harnesses, Ignitions, Electric Starter, Key Switch  
543477-1122-E1 Alternators, Wiring Harnesses, Ignitions, Electric Starter, Key Switch  
543477-1129-E1 Alternators, Wiring Harnesses, Ignitions, Electric Starter, Key Switch  
543477-1131-E1 Alternators, Wiring Harnesses, Ignitions, Electric Starter, Key Switch  
543477-1140-E1 Alternators, Wiring Harnesses, Ignitions, Electric Starter, Key Switch  
543477-1142-E1 Alternators, Wiring Harnesses, Ignitions, Electric Starter, Key Switch  
543477-1146-E1 Alternators, Wiring Harnesses, Ignitions, Electric Starter, Key Switch  
543477-1147-E1 Alternators, Wiring Harnesses, Ignitions, Electric Starter, Key Switch  
543477-1158-E1 Alternators, Wiring Harnesses, Ignitions, Electric Starter, Key Switch  
543477-1159-E1 Alternators, Wiring Harnesses, Ignitions, Electric Starter, Key Switch  
543477-1165-E1 Alternators, Wiring Harnesses, Ignitions, Electric Starter, Key Switch  
543477-1168-E1 Alternators, Wiring Harnesses, Ignitions, Electric Starter, Key Switch  
543477-1169-E1 Alternators, Wiring Harnesses, Ignitions, Electric Starter, Key Switch  
543577-0110-E1 Alternator, Regulator, Wires, Controls, Springs, Electric Starter  
543777-0100-E1 Controls, Springs, Alternator, Ignition, Wires, Electric Starter  
543777-0110-E1 Controls, Springs, Alternator, Ignition, Wires, Electric Starter  
543777-0110-E2 Controls, Springs, Alternator, Ignition, Wires, Electric Starter  
543777-0120-E1 Controls, Springs, Alternator, Ignition, Wires, Electric Starter  
543777-0121-E1 Controls, Springs, Alternator, Ignition, Wires, Electric Starter  
543777-0123-E1 Controls, Springs, Alternator, Ignition, Wires, Electric Starter

Page 19 of 24

543777-1110-E2 Controls, Springs, Alternator, Ignition, Wires, Electric Starter  
543777-1120-E1 Controls, Springs, Alternator, Ignition, Wires, Electric Starter  
543777-1121-E1 Controls, Springs, Alternator, Ignition, Wires, Electric Starter  
610177-0100-E1 Alternator, Ignition, Flywheel, Starter Motor, Controls, Springs  
611177-0100-E1 Controls, Electric Starter, Alternator, Ignition, Governor Springs, Flywheel  
611475-0119-E1 Alternator, Electric Starter, Ignition, Wires  
611477-0110-E1 Alternator, Electric Starter, Ignition, Wires  
611477-0111-E1 Alternator, Electric Starter, Ignition, Wires  
611477-0112-E1 Alternator, Electric Starter, Ignition, Wires  
611477-0113-E1 Alternator, Electric Starter, Ignition, Wires  
611477-0121-E1 Alternator, Electric Starter, Ignition, Wires  
611477-0122-E1 Alternator, Electric Starter, Ignition, Wires  
611477-0123-E1 Alternator, Electric Starter, Ignition, Wires  
611477-1121-E1 Alternator, Electric Starter, Ignition, Wires  
612177-0100-E1 Controls, Alternator, Ignition, Flywheel, Governor Spring, Links, Electric Starter  
613177-0100-E1 Alternator, Ignition, Flywheel, Starter Motor, Controls, Springs  
613177-0112-E1 Alternator, Ignition, Flywheel, Starter Motor, Controls, Springs  
613177-0113-E1 Alternator, Ignition, Flywheel, Starter Motor, Controls, Springs  
613177-0114-E1 Alternator, Ignition, Flywheel, Starter Motor, Controls, Springs  
613177-0115-E1 Alternator, Ignition, Flywheel, Starter Motor, Controls, Springs  
613177-0116-E1 Alternator, Ignition, Flywheel, Starter Motor, Controls, Springs  
613277-0110-E1 Alternator, Ignition, Electric Starter, Engine Gasket Set, Valve Gasket Set  
613477-0035-E1 Alternator, Wires, Electric Starter, Ignition  
613477-0038-E1 Alternator, Wires, Electric Starter, Ignition  
613477-0048-E1 Alternator, Wires, Electric Starter, Ignition  
613477-0076-E1 Alternator, Wires, Electric Starter, Ignition  
613477-0078-E1 Alternator, Wires, Electric Starter, Ignition  
613477-0079-E1 Alternator, Wires, Electric Starter, Ignition  
613477-0100-E1 Alternator, Wires, Electric Starter, Ignition





613777-0110-E1 Ignition, Electric Starter, Alternators, Oil Cooler, Wire Harnesses

613777-0110-E2 Ignition, Electric Starter, Alternators, Oil Cooler, Wire Harnesses

613777-0111-E1 Ignition, Electric Starter, Alternators, Oil Cooler, Wire Harnesses

613777-1110-E2 Ignition, Electric Starter, Alternators, Oil Cooler, Wire Harnesses

Page 24 of 24