



Note: Unless you are sure of your part number, please email us your model & spec number so we can ensure you get the right part and that there are no further modifications required.

Parts look up sometimes depends on a variety of issues (such as date code or other markings) The list below is derived from a "where used" search of either the part in question or a superseded (prior) part and can not take into account potential part variations that depend on other factors (such as date code) Unless you are 100% sure this is your part you should verify by looking the part up at either **www.smallenginepartssuppliers.com**

www.smallenginepartssuppliers.com

No claim of wrong part received will be honored based on the information presented in this file. You must have a WRITTEN (via email) recommendation to claim wrong part received.

The alternator or regulator below can be found at the following page:

http://www.smallenginesuppliers.com/shop/html/pages/Briggs_Stratton_ignition_coil.html

Where Used: 790320

Model Name Diagram

121232-0144-B8 Controls, Governor Spring, Ignition
121232-0156-B8 Controls, Governor Spring, Ignition
121236-0142-B8 Controls, Governor Spring, Ignition
121336-0222-B1 Controls, Electric Starter, Governor Springs, Ignition
121336-0222-B8 Controls, Electric Starter, Governor Springs, Ignition
122337-4182-B8 Controls, Governor Spring, Ignition
122337-4245-B8 Controls, Governor Spring, Ignition
122437-0245-01 Controls, Governor Spring, Ignition
123336-0180-B1 Controls, Electric Starter, Governor Spring, Ignition
123336-0180-E1 Controls, Electric Starter, Governor Spring, Ignition
123337-0182-B8 Controls, Electric Starter, Governor Spring, Ignition
123337-0182-E8 Controls, Electric Starter, Governor Spring, Ignition
12H337-0132-B8 Controls, Governor Spring, Ignition
12L332-0115-F8 Controls, Governor Spring, Ignition
12L336-0107-F8 Controls, Governor Spring, Ignition
12L336-0111-F8 Controls, Governor Spring, Ignition
12L337-0113-F8 Controls, Governor Spring, Ignition
13H332-0036-B1 Alternator, Ignition
13H332-0036-B8 Alternator, Ignition
13H332-0111-B8 Alternator, Ignition
13H332-0112-B8 Alternator, Ignition
13H332-0113-B8 Alternator, Ignition
13H332-0114-B8 Alternator, Ignition
13H332-0115-B8 Alternator, Ignition
13H332-0116-B8 Alternator, Ignition

13H332-0120-B8 Alternator, Ignition
13H332-0124-B1 Alternator, Ignition

Page 1 of 3

13H332-0125-B8 Alternator, Ignition
13H332-0126-B8 Alternator, Ignition
13H332-0127-B8 Alternator, Ignition
13H332-0130-B8 Alternator, Ignition
13H332-0132-B8 Alternator, Ignition
13H332-0133-B8 Alternator, Ignition
13H332-0134-B8 Alternator, Ignition
13H332-0137-B8 Alternator, Ignition
13H332-0138-B8 Alternator, Ignition
13H332-0139-B8 Alternator, Ignition
13H332-0140-B8 Alternator, Ignition
13H332-0141-B8 Alternator, Ignition
13H332-0142-B8 Alternator, Ignition
13H332-0144-B8 Alternator, Ignition
13H332-0146-B8 Alternator, Ignition
13H332-0149-B8 Alternator, Ignition
13H332-0153-B8 Alternator, Ignition
13H332-0154-B8 Alternator, Ignition
13H332-0156-B8 Alternator, Ignition
13H332-0157-B8 Alternator, Ignition
13H332-0159-B8 Alternator, Ignition
13H336-0131-B8 Alternator, Ignition
13H337-0117-B8 Alternator, Ignition
13H337-0118-B8 Alternator, Ignition
13H337-0128-B8 Alternator, Ignition
13H352-0119-B8 Alternator, Ignition
13H352-0136-B8 Alternator, Ignition
13H362-0121-B8 Alternator, Ignition
13H362-0143-B8 Alternator, Ignition

Page 2 of 3

13H362-0145-B8 Alternator, Ignition
13H362-0152-B8 Alternator, Ignition
13L336-0110-F8 Alternator, Ignition
20L136-0113-F1 Ignition

Page 3 of 3