

The engines below use the gasket set shown after "Where Used:"

You can buy the gasket set at the link given below

http://www.smallenginesuppliers.com/shop/html/pages/Briggs_Gasket_Set.html

Where Used: 495993

Model Name	Diagram
287707-0026-01	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-0101-01	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-0102-01	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-0112-01	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-0115-01	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-0116-01	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-0117-01	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-0119-01	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-0120-01	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-0121-01	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-0122-01	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-0153-01	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-0156-01	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-0201-01	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-0210-01	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-0211-01	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-0212-01	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-0213-01	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-0215-01	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-0216-01	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-0220-01	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-0224-01	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-0224-02	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-0225-01	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-0227-01	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-0228-01	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-0229-01	Cylinder, Piston/Ring, Crankshaft, Sump, Kits

287707-0230-01	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-0231-01	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-0232-01	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-0233-01	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-0235-01	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-0246-01	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-0247-01	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-0249-01	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-0255-01	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-0272-01	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-0622-A1	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-0625-A1	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-0634-A1	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-0644-A1	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-0648-A1	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-1005-E1	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-1026-E1	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-1036-E1	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-1122-E1	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-1201-E1	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-1210-E1	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-1220-E1	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-1224-E1	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-1225-E1	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-1227-E1	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-1228-E1	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-1229-E1	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-1230-E1	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-1231-E1	Cylinder, Piston/Ring, Crankshaft, Sump, Kits

287707-1232-E1	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-1235-E1	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-1236-E1	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-1238-E1	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-1239-E1	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-1240-E1	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-1241-E1	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-1246-E1	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-1249-E1	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-1250-E1	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-1255-E1	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-1255-E3	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-1257-E1	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-1258-E1	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-1259-E1	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-1260-E1	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-1261-E1	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-1263-E1	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-1272-E1	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-1273-E1	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-1274-E1	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-1275-E1	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-1277-E1	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-1277-E3	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-1279-E1	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-1286-E1	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-1288-E1	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287707-1290-E1	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287776-1237-E1	Cylinder, Piston/Ring, Crankshaft, Sump, Kits

287776-1281-E1	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287777-0256-01	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287777-0256-02	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287777-0656-A1	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287777-1006-E1	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287777-1256-E1	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287777-1256-E2	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287777-1276-E1	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287777-1276-E3	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287777-1278-E1	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287777-1278-E3	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287777-1283-E1	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
287777-1287-E1	Cylinder, Piston/Ring, Crankshaft, Sump, Kits
28N707-0026-01	Crankcase Cover/Sump, Crankshaft, Cylinder, Piston/Rings, Connecting Rod
28N707-0036-01	Crankcase Cover/Sump, Crankshaft, Cylinder, Piston/Rings, Connecting Rod
28N707-0101-01	Crankcase Cover/Sump, Crankshaft, Cylinder, Piston/Rings, Connecting Rod
28N707-0102-01	Crankcase Cover/Sump, Crankshaft, Cylinder, Piston/Rings, Connecting Rod
28N707-0108-01	Crankcase Cover/Sump, Crankshaft, Cylinder, Piston/Rings, Connecting Rod
28N707-0109-01	Crankcase Cover/Sump, Crankshaft, Cylinder, Piston/Rings, Connecting Rod
28N707-0111-01	Crankcase Cover/Sump, Crankshaft, Cylinder, Piston/Rings, Connecting Rod
28N707-0112-01	Crankcase Cover/Sump, Crankshaft, Cylinder, Piston/Rings, Connecting Rod
28N707-0113-01	Crankcase Cover/Sump, Crankshaft, Cylinder, Piston/Rings, Connecting Rod
28N707-0114-01	Crankcase Cover/Sump, Crankshaft, Cylinder, Piston/Rings, Connecting Rod
28N707-0114-02	Crankcase Cover/Sump, Crankshaft, Cylinder, Piston/Rings, Connecting Rod
28N707-0115-01	Crankcase Cover/Sump, Crankshaft, Cylinder, Piston/Rings, Connecting Rod
28N707-0117-01	Crankcase Cover/Sump, Crankshaft, Cylinder, Piston/Rings, Connecting Rod
28N707-0117-02	Crankcase Cover/Sump, Crankshaft, Cylinder, Piston/Rings, Connecting Rod
28N707-0120-01	Crankcase Cover/Sump, Crankshaft, Cylinder, Piston/Rings, Connecting Rod
28N707-0121-01	Crankcase Cover/Sump, Crankshaft, Cylinder, Piston/Rings, Connecting Rod

28N707-1145-E1	Crankcase Cover/Sump, Crankshaft, Cylinder, Piston/Rings, Connecting Rod
28N707-1166-E1	Crankcase Cover/Sump, Crankshaft, Cylinder, Piston/Rings, Connecting Rod
28N707-1171-E1	Crankcase Cover/Sump, Crankshaft, Cylinder, Piston/Rings, Connecting Rod
28N707-1173-E1	Crankcase Cover/Sump, Crankshaft, Cylinder, Piston/Rings, Connecting Rod
28N707-1177-E1	Crankcase Cover/Sump, Crankshaft, Cylinder, Piston/Rings, Connecting Rod
28N707-1181-E1	Crankcase Cover/Sump, Crankshaft, Cylinder, Piston/Rings, Connecting Rod
28N707-1189-E1	Crankcase Cover/Sump, Crankshaft, Cylinder, Piston/Rings, Connecting Rod
28N707-1190-E1	Crankcase Cover/Sump, Crankshaft, Cylinder, Piston/Rings, Connecting Rod
28N707-1192-E1	Crankcase Cover/Sump, Crankshaft, Cylinder, Piston/Rings, Connecting Rod
28N707-1196-E1	Crankcase Cover/Sump, Crankshaft, Cylinder, Piston/Rings, Connecting Rod
28N707-1201-E1	Crankcase Cover/Sump, Crankshaft, Cylinder, Piston/Rings, Connecting Rod
28N707-1203-E1	Crankcase Cover/Sump, Crankshaft, Cylinder, Piston/Rings, Connecting Rod
28N707-1204-E1	Crankcase Cover/Sump, Crankshaft, Cylinder, Piston/Rings, Connecting Rod
28N707-1205-E1	Crankcase Cover/Sump, Crankshaft, Cylinder, Piston/Rings, Connecting Rod
28N777-0103-01	Crankcase Cover/Sump, Crankshaft, Cylinder, Piston/Rings, Connecting Rod
28N777-0119-01	Crankcase Cover/Sump, Crankshaft, Cylinder, Piston/Rings, Connecting Rod
28N777-0130-01	Crankcase Cover/Sump, Crankshaft, Cylinder, Piston/Rings, Connecting Rod
28N777-0174-01	Crankcase Cover/Sump, Crankshaft, Cylinder, Piston/Rings, Connecting Rod
28N777-0182-01	Crankcase Cover/Sump, Crankshaft, Cylinder, Piston/Rings, Connecting Rod
28N777-0642-A1	Crankcase Cover/Sump, Crankshaft, Cylinder, Piston/Rings, Connecting Rod
28N777-0682-A1	Crankcase Cover/Sump, Crankshaft, Cylinder, Piston/Rings, Connecting Rod
28N777-1103-E1	Crankcase Cover/Sump, Crankshaft, Cylinder, Piston/Rings, Connecting Rod
28N777-1130-E1	Crankcase Cover/Sump, Crankshaft, Cylinder, Piston/Rings, Connecting Rod
28N777-1143-E1	Crankcase Cover/Sump, Crankshaft, Cylinder, Piston/Rings, Connecting Rod
28N777-1174-E1	Crankcase Cover/Sump, Crankshaft, Cylinder, Piston/Rings, Connecting Rod
28N777-1178-E1	Crankcase Cover/Sump, Crankshaft, Cylinder, Piston/Rings, Connecting Rod
28N777-1182-E1	Crankcase Cover/Sump, Crankshaft, Cylinder, Piston/Rings, Connecting Rod
28N777-1194-E1	Crankcase Cover/Sump, Crankshaft, Cylinder, Piston/Rings, Connecting Rod
28N777-1194-E2	Crankcase Cover/Sump, Crankshaft, Cylinder, Piston/Rings, Connecting Rod

28Q777-0102-01	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0112-01	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0116-01	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0117-01	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0128-01	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0129-01	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0136-01	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0139-01	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0140-01	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0144-01	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0148-01	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0149-01	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0150-01	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0151-01	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0155-01	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0155-02	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0156-01	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0164-01	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0165-01	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0166-01	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0167-01	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0168-01	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0526-E1	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0526-E2	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0536-A1	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0536-E1	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0601-E1	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0602-E1	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0612-A1	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod

28Q777-0613-A1	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0616-E1	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0623-A1	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0624-01	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0624-A1	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0627-A1	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0627-A2	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0630-A1	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0631-E1	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0636-E1	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0639-E1	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0641-A1	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0641-E1	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0642-A1	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0645-E1	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0646-A1	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0646-E1	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0647-A1	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0647-E1	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0650-A1	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0655-A1	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0655-A2	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0656-A1	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0662-E1	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0664-A1	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0667-A1	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0668-E1	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0670-A1	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0670-E1	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod

28Q777-0671-A1	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0672-E1	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0673-E1	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0674-E1	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0675-A1	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0675-E1	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0676-A1	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0677-E1	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0678-E1	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0679-E1	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0681-01	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0687-E1	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0687-E3	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0688-E1	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0690-E1	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0691-E1	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0692-E1	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0693-E1	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod
28Q777-0694-E1	Crankshaft, Sump, Cylinder, Piston/Rings, Connecting Rod